

Index

1. Product line-up	3
2. Internal circuit	4
3. Applications of IPM to general purpose Inverter	5
4. Term explanation	6
5. Numbering system	7
6. Structure	8
7. Safety use of power module	12
8. Installation of power module	15
8-1. Installing capacitor	15
8-2. Installation hints	15
8-3. Coating method of thermal grease	16
8-4. Connecting the Interface circuit	17
8-5. Terminal of IPM	18
9. Using IPM	19
9-1. Instruction of the symbol for IPM terminal	19
9-2. Function of the IPM	21
9-3. Safe operating area for IPM	22
9-4. Fault signal of IPM	23
9-5. Interface circuit requirements	27
9-6. Control power supply of IPM	28
9-7. Applications of IPM G1-series to motor drive	29
9-8. Interface circuit for IPM	30
9-9. Other notice of using IPM	31
9-10. Design of control power supply for IPM	32
9-11. Fo circuit	33
10. Power loss and Junction temperature	34
11. Notice for safe designs and using this appreciation note	35
	